

TECHNICAL PAPER

Elastomer Seals – Purity or plasma resistance, can you have both?

Knut Beekmann
Semiconductor Business Line Leader

Precision Polymer Engineering

www.prepol.com



The choice of seal materials available to end users can be bewildering. Without the luxury of having test chambers or fab production equipment dedicated to testing a multitude of seal materials in the various applications, the choice becomes a potentially risky one, which involves making a change and running live product using a new seal. The effort must therefore be rewarded with a cost saving that is commensurate with the risk or resource required to carry out such a test. Such a saving can be achieved either through an extension of the uptime cycle, a reduction in the part cost or, a combination of the two.

In order to greatly alleviate the risk of incorrect seal choice, potentially leading to scrapped product or wasted test resource, a comprehensive study has been carried out to benchmark seal materials from the leading elastomer O-ring suppliers. The creation and maintenance of such a database serves to greatly offset the risk associated with changing a seal material in order to reduce CoC and increase profitability or competitiveness.

Methodology

End users often run processes that are tuned to individual needs. It is also normal practice for manufacturers to keep such detailed process information confidential. To test every seal material in every process would be an impractical task. There are however, common chemistries used in plasma etch and deposition and this study was designed to test the various different elastomer materials in the more aggressive chemistries and plasma conditions. The process chemistries chosen are commonly used for etching of silicon, metals, compound semiconductors, dielectrics, resist ashing and particularly aggressive deposition chamber etch. Various different plasma modes were also employed, reflecting a variety of different process requirements. This included direct parallel plate, high density remote inductively coupled plasma (ICP) and sources specifically designed to create high radical and in particular, high fluorine radical content.

In all cases, elastomer materials were placed on the substrate holder on a carrier and subjected to the various process chemistries and plasma sources for fixed periods of time. The substrate holder was not biased to more closely represent the case where a seal would sit within a groove or retaining feature and as a result, would not normally be subject to significant ion bombardment. Materials were evaluated for their relative erosion rates or, mass loss and observation of surface particle formation. TGA spectra were also carried out in order to determine the nature of the material compound and in particular

whether the material was purely organic and filler free, contained organic filler or, contained inorganic filler. The process chemistries chosen were:

1. O₂ in a direct parallel plate plasma system
2. O₂ in a remote ICP system
3. Cl₂, BCl₃, HBr in a remote ICP system
4. SF₆, O₂ in a remote ICP system
5. SF₆ in a low volume ICP optimized high radical plasma system



Figure 1: Oxford Instruments PlasmaPro System133 ICP380



Figure 2: Oxford Instruments PlasmaPro System100 ICP65

The fillers used in the compounding play an important role in the plasma resistance of the elastomers. Most organic polymers have higher etch rates than the fillers. In order to achieve optimum etch resistance, organic polymers are usually compounded with various types of fillers. The filler particles shield the organic backbone of the elastomer from erosion and therefore improve the plasma resistance of the elastomer material. The filler particles which are dispersed and trapped within the polymer matrix however; can become free after the polymer matrix is etched away. These free particles on the elastomeric seal can cause contamination and therefore reduce product yields in chemically aggressive processes. In order to minimize the risk of particle contamination and decrease erosion rates, some advanced filler systems can be used in the plasma resistant elastomeric material formulation.

Minerals, metal oxides and synthetic fillers are some examples of advanced filler systems. In general, the fillers can be classified in two groups as organic and inorganic fillers. Inorganic fillers provide better erosion resistance when compared with organic fillers because of their rigid crystal structure and relative chemical stability. The chance of contamination however, is generally lower when organic fillers or no fillers are used in the elastomer formulation, with the disadvantage that erosion rates are considerably higher than their inorganic filled counterparts.



Nanofluor® Y75G nano-filled fluoroelastomer

A residue is observed in the inorganic filled elastomer even at high temperature after the organics in the formulation are fully decomposed. The amount of remaining residue corresponds to the amount of filler used in the formulation (Figure 3C).

As mentioned above, the chance of particle formation and hence contamination, by using an unfilled or organic filled elastomer is lower than that from a traditional inorganic filled material but the etch rates of inorganics are lower than the organic filled or the unfilled polymers. This paradox can be resolved by using an advanced inorganic filler system which also significantly minimizes the risk of contamination. The use of lower amounts of filler with maximized surface




Figure 3. Thermogravimetric analysis (TGA) curves of A filler-free, B organic and C inorganic filled elastomer materials.

Results

The Thermogravimetric Analysis (TGA) curves in Figure 3 show the differences between the elastomer formulations with different filler types. A pure elastomer formulation with no fillers decomposes completely at around 500°C leaving no residue (Figure 3A). Similarly, a formulation prepared using an organic filler also fully decomposes at around 600°C without leaving any residue. In this case, the decomposition of organic filler can be observed in the TGA by a characteristic shoulder at slightly higher temperature than the polymer degradation (Figure 3B).

area is an ideal solution. A filler system with very high surface area has very small particles, ideally in the nanometer size range and they need to be well dispersed.

In Figure 4, the plasma erosion rates of several different fluoroelastomers are graphically presented. Perlast® G67G and Nanofluor® Y75G have been found to provide very good plasma resistance in a variety of chemistries. These grades have been uniquely compounded with relatively low levels of an advanced, non-metal oxide, nano-filler system which has an average particle size of 25-40 nm.




Figure 4 - Summary of the weight loss of various competitor, current and development PPE grades upon exposure to O₂ (Direct and remote), SF₆/O₂, Cl₂ (BCl₃ / HBr) and high radical SF₆ plasmas.

The dispersion of nano-fillers¹ in the elastomer formulation is another very important factor for determining the plasma etch resistance and potential for particle contamination upon plasma exposure. Nano-fillers must be perfectly dispersed in the polymer matrix to achieve maximum plasma etch resistance and minimum chance of contamination of the wafer or substrate being processed.

Nanoparticles have very high surface energy and very large surface area. In order to diminish this energy, they naturally prefer to form agglomerates or clumps which consist of several or up to several hundreds of individual nanoparticles². These agglomerates must be broken into single nanoparticles when compounding and dispersed uniformly in the polymer matrix. If this is not achieved, these agglomerates will behave as macro sized particles and can be released as micron sized defects upon plasma erosion. This phenomenon can be seen in the cross-sectional SEM image of an unused sample, Figure 5A, which is a very good example of poor filler dispersion. However, as can be seen in Figure 5B, Nanofluor® Y75G exhibits excellent nano filler dispersion and therefore provides significantly reduced chance of contamination or, generation of killer defects.

Providing a smooth surface after plasma erosion is also very important for critical sealing applications. Excellent dispersion results in a smooth surface even after plasma exposure. Poor dispersion causes a rough and uneven surface as a result of inconsistent etch rates on the surface (Figure 5A).




Figure 5A




Figure 5B

The TGA analyses of grade B2, Perlast® G67G and Nanofluor® Y75G in Figure 7 shows that the amount of nano-filler used in grade B2 is 20-35% higher than in either G67G or Y75G respectively. This therefore leads to a higher risk of particle contamination from grade B2.




Figure 6A




Figure 6B




Figure 7 - TGA curves of Nanofluor® Y75G, Perlast® G67G and Grade B2.

Summary

During aggressive vacuum wafer processing, elastomer seals in key tool locations will be subject to wear during normal operation and will expose the wafer to the degradation byproducts of the elastomer material and also to any compounded materials contained within the elastomer. As evidenced by the erosion rates, there is inevitably a compromise between using seal materials that are completely free from any filler and organic fillers and those that use inorganic filler systems although some overlap between materials can be seen. The best solution is generally to use inorganic materials which have well dispersed nano-fillers in the compound, which therefore offer optimized erosion and hence seal lifetime and greatly reduced chance of yield limiting particle contamination.

References:

1. Mark, J. E.; Erman, B.; Eirich, F.R. (Eds.) (2013) *The Science and Technology of Rubber* (4th Ed); Elsevier Inc., Oxford, UK. ISBN: 978-0-12-394584-6
2. Walter, D. (2013) *Primary Particles – Agglomerates – Aggregates*, in *Nanomaterials* (ed Deutsche Forschungsgemeinschaft (DFG)), Wiley-VCH Verlag GmbH & Co. KGaA, Weinheim, Germ

Global Headquarters

Precision Polymer Engineering
Greenbank Road
Blackburn, BB1 3EA
England
T: +44 (0)1254 295 400
E: sales@idexcorp.com

Americas

Precision Polymer Engineering LLC
3201 S. Blue Bell Road
Brenham, TX 77833
USA
T: +1 979 353 7350
E: prepol.sales-usa@idexcorp.com

2045 Martin Avenue, Suite 206
Santa Clara, CA 95050
USA
T: +1 408 441 2043
E: prepol.sales-usa@idexcorp.com

Perlast® and Nanofluor® are registered trademarks of Precision Polymer Engineering Ltd.

Disclaimer

The content provided in this technical paper is intended solely for general information purposes, and is provided with the understanding that the authors and publishers have taken reasonable care and attention. This information is to the best of our knowledge accurate and reliable. However, it is possible that some information in this technical paper is incomplete, incorrect, or not applicable to particular circumstances or conditions. Any use of this information should be done only in consultation with a qualified and licensed professional who can provide specific advice based on a given application, taking into account all relevant factors and desired outcomes. We do not accept liability for direct or indirect losses resulting from using, relying or acting upon information in this technical paper.

TP00116-16/20



Precision Polymer Engineering is a Unit of IDEX Corporation